

Aprilia Display Cheat Sheet

Left Display:

Settings:

km/h <-> mph: A(5 sec), B, A(5 sec)

Reset service indication: Lap, R(5 sec)

While stationary:

Reset trip counter: R(2 sec)

Show max. speed: B(1 sec)

Reset max. speed: B(1 sec), R(2 sec)

Show avg. spd & 2nd trip: B(1 sec), B(1 sec)

Reset avg. spd & 2nd trip: B(1 sec), B(1 sec), R(1 sec)

Lap Timer:

Enable: Lap, D

Start timer: Lap

Lap time: Lap (display lap time & start new lap)

Display stored times: B, Lap (cycle through up to
40 laps)

Return to lap timer: B

Reset stored lap times: A + Lap(2 sec)

Exit lap timer: Lap + D

Right Display:

D cycles:

- Temp & Time
- Batt. Voltage
- Clock: Set hours
- Clock: Set minutes
- Temp: Set deg. C/F

(Lap to set hours/minutes/units)

Display Test:

Switch on ignition while
pressing A + B

Rev limit indicator:

Set: C, C(hold/press
repeatedly)

Show: C(short)

*(Rev limit indicator can only
be set with engine off)*

Legend:

"A(5 sec)" means press button A for 5 seconds

"A + Lap" means press button A and the Lap button together

*This reference applies to Aprilia V-Twins
RSV Mille and SL Mille*

*(c) 2001 Markolf Gudjons <adcs@mtnsb.org>
All rights reserved - duplication for private use permitted*